

EZee Life™

EZee Fold Bariatric Electric Folding Wheelchair User Manual

Model: CH4075



EZee Life™ Products

34 Futurity Gate, Unit 15
Concord, Ontario L4K 1S6



Table of Contents

Guidance for Use	3
Product Safety Symbols	4
Technical Specifications	5
Components	6
Electromagnetic Interference Warning	7
Safety	8
Operation Guide	13
Troubleshooting	17
Braking	19
Battery	20
Unfolding and Folding	24
Warranty	28
Packing List	29

Guidance for Use

This manual must be read and understood completely before your first use. If you have difficulty in understanding the warnings, notes and instructions in this owner’s manual, or require additional assistance, please contact your authorized provider or distributor to obtain professional guidance and help.

Failure to follow the instructions on this manual can lead to your safety being at risk as result of improper usage and voiding the warranty.

Authorized Provider: _____

Address: _____

Phone Number: _____

Purchase Date: _____



Product Safety

The following symbols are used to identify warnings, mandatory actions and prohibited actions. It is essential that you fully understand and completely familiarize yourself with these symbols before operating wheelchair for the first time.

-  Read and follow the instructions provided in this manual.
-  Safety warning sign or an indication of a dangerous operation that may endanger your safety or the safety of others.
-  Class I equipment (Canada) / Class II equipment (USA).
-  Do not use any mobile phones, walkie talkies, electronic devices or any other radio transmitters while operating.
-  Finger crush / pinch point.
-  Store in a clean and dry condition; away from rain, snow, ice, salt and water.
-  Test of EMI/RFI at an immunity level of 30 V/m has been passed.
-  Corrosive substance contained in the battery
-  Danger of explosion
-  Do not use batteries with different amp-hour (Ah) capacities, do not mix use of old and new batteries. Always replace both batteries at the same time.
-  Keep tools and other metal objects away from battery terminals. If contacted, short circuit or electric shock may occur and cause injury.
-  Flammable material, avoid exposure to heat source such as open flame or sparks. Avoid transporting the batteries along with flammable or combustible objects.
-  Disposal and recycle

Technical Specifications

Specification	Value
Dimensions (open L x W x H)	1280 x 656 x 405 mm
Dimensions (folded L x W x H)	656 x 448 x 824 mm
Weight Capacity	227 kg (500 lbs.)
Base Weight	35 kg (77 lbs.)
Driving Range*	20 km* (12.5 miles)
Max Speed *	8 kph* (5 mph)
Turning radius	991 mm (39")
Maximum Ground Clearance	635 mm (2.5")
Seat Size (W x D)	508 x 508 mm (20" x 20")
Max. Climbing Grade:	12 degrees

*Will vary with user's weight, terrain, ground condition, battery condition, temperature and driving style.

Battery Size	24 volts / 20 Ah
Battery Charger	Off Board, 5 amps.
Braking System	Intelligent braking (electronic, regenerative disc brakes)
Drive Type	Two motor, rear wheel drive
Drive Wheels	12" Pneumatic tire
Front Wheels	8" Pneumatic tire
Suspension	Spring Absorber



Components:



1. Footrest	8. Anti-Tipper
2. Frame	9. Drive Wheel
3. Seat Cushion	10. Frame Connector Block
4. Joystick	11. Front Caster
5. Armrest	12. Electromagnetic brake lever
6. Backrest	13. Battery
7. Fender	14. Folding Release Lever



Electromagnetic Interference Warning

The power wheelchair may be affected by electromagnetic interference (EMI), which may cause damage or interruption to the operation of the chair. It is important for you to understand the instructions which can help you take protective measures against the risk of interference.

The sources of electromagnetic waves come from broadcasting stations, TV stations, radio transmitters, two-way radios (such as walkie-talkies), cellular phones and computers. Interference from these electromagnetic waves may cause malfunction or permanent damage to the chair's braking and control system.



CAUTION!

1. The power wheelchair has passed the 30 V/m EMI test and has a certain degree of immunity to most common electromagnetic energy sources.

However, it is important for you to follow the safety guidelines as follows:

- a. Do not turn on or operate portable transceivers, receivers, radios or any wireless communication devices.
 - b. Stay away from all radio wave emission sources.
2. If interference does occur and causes unintended movement to the chair in an uncontrolled manner, cut off the power immediately.
3. No modification of any form to the power wheelchair is allowed, including adding or removing any parts.





Usage Safety Guidelines

- Check all electrical and control connections to ensure they are secured safely and firmly.
- Check battery levels regularly and ensure the battery is charged immediately when needed.
- Keep tools and any metal objects away from the negative and positive poles of the battery.
- Short-circuits or electric shock may occur when the two poles are accidentally contacted.
- Familiarize yourself with wheelchair and its capabilities.
- Always seek assistance during your first use until you are confident enough to operate the chair independently and proficiently.
- Always beware of any potential danger while using the power wheelchair.
- When the power wheelchair is not in use, turn off the power, charge the battery and store in a clean and dry place.

Static Position

When the chair is inactive even for a moment; the power must be off.

This will:

- Prevent the control panel from being activated by accidental touch which may cause the chair to move unintentionally.
- Prevent the chair from electromagnetic interference sources which may activate the chair's operation system and cause damage to the chair and bodily harm.

Do not allow anyone but you to touch the control panel. This will protect the chair from being moved without your awareness and causing potential serious bodily harm.



Weather Precautions

This power wheelchair shall not be used or stored in environments of rain, snow, icy or slippery surfaces. These conditions may adversely affect the functions of the chair. Always keep your chair in a clean and dry area.

Malfunction may occur if the device is in contact with rain, snow or high humidity environments. Do not expose the chair to any extremely hot or cold conditions. The chair is not fully waterproof; a humid environment may result in rusting or corrosion inside the chair. If you are ever caught in any of these conditions, please proceed to shelter immediately.

To prevent malfunction, please adhere to the guidelines as follows:

- Do not operate or store the chair in an environment which has direct water contact extremely hot or cold temperature or high humidity.
- Do not use the chair while showering, swimming, etc.
- Do not use the chair in salt or fresh water.
- Do not use the chair around any water sources (e.g. rivers, lakes, etc.)
- Do not flush the chair with water.

Note: When the chair is wet, immediately pull out the battery and allow it to dry naturally. Put the battery back after the chair is completely dried.

When operating on wet or frictionless ground surfaces, please carefully move at a slow speed and follow the safety guidelines below:

- When any of the motor wheels losses traction, the chair must be stopped immediately to avoid losing control of the chair (e.g. slipping, tipping over, etc.).
- Do not drive into slopes or ramps covered with snow, ice, water, oil, etc.

Road Surfaces

This wheelchair is designed optimally for dry level surfaces; such as concrete and indoor ground flooring.

Do not use wheelchair on sand, uneven or loose surfaces, tall grass or rough road surfaces to prevent the wheels, bearings, axis, motor and other parts from being damaged or loosened.



Vehicle Transport



Please be aware that it is at your own risk and is not advisable to sit in the wheelchair when taking any forms of transportation such as cars, buses, trains, planes or ships.

If you must take such forms of transportation while remaining in the chair, it is extremely important that you secure your positioning waist belt and power off the chair and push the brake lever to “Lock” position, inspect no movement to the motor wheels and have the chair securely tied down. This will help prevent injuries during sudden stops. However, as this chair is ultra-compact, taking any transportation is made possible as you can fold the chair conveniently and can be stored away in tight storage areas such as a car trunk. Please ensure the chair is stored securely in order to avoid injury.

If you need to be transferred on or off a vehicle manually without getting off the chair, never allow anyone to lift the chair by the armrest or rear backrest. The chair must be lifted by firmly gripping the front and rear edges of the seat cushion frame.

Weight Distribution

To avoid tipping over while driving, the balance and stability of the power wheelchair must not be neglected. The following factors may affect the weight distribution of the chair:

- Height and angle of the chair.
- Seating position, or weight loading position of the user’s body.
- The gradient of the ramp or slope.
- Load carried in storage basket or by the user may have adverse effects to the weight distribution of the chair.

Getting On/Off

Whenever moving your body, it is recommended to have a supporting point that is higher than the seat cushion. To avoid and reduce the chance of falling, please be aware of the following:

- Before getting on and off the chair, ensure that you lift up the armrest and lower the leg guard.
- Before getting on the chair, ensure that the power is off, and the brake is in “Lock” position. Inspect that there is no movement to the motor wheels.
- Before getting out of the chair, ensure that the power is off, and the brake is in “Lock” position. Inspect that there is no movement to the motor wheels. Move the chair as close as possible to the target position to minimize the risk of falling during transfer.

- Consult your health care professionals about the safest way to move your body in and out of the chair.
- Fold up the footrest at all times while getting on and off the chair
 - Do not stand on the footrest to move your body while getting on/off the chair.
 - Make sure your feet are not tangled or jammed in the gap between the footrest while getting on/off the chair.

Leaning or Reaching while Seated

Reaching out your hands or leaning your body in the chair may adversely affect the chair's balance. If you do not position yourself correctly, you may fall off or tip over the chair.

- When moving your body such as lifting your body at one side or leaving the seat do not lean your body out of the range of the seat cushion.
- When moving forward on your seat, do not lean your body excessively. Your hip must be always in contact with the seat cushion.
- Do not reach your hands farther than your capability as this may result in falling due to lost balance.
- Under no circumstance should you try to pick up anything through the space between your knees or in front of your body.
- When you extend your body, do not exert force on the footrest to avoid the chair from tipping over, this may result in serious injury.
- Do not rest forcefully against the top of the backrest to avoid tipping over the chair and causing damage to the backrest.



Failing to follow these guidelines may result in serious injury. If you do any of these actions, it is at your own risk.



Never reach, bend, or lean in the chair. Doing so will change your center of gravity and the weight distribution of the chair.

Stationary Obstacles

Navigating over obstacles such as ramps, slopes, curbs, raised or uneven surfaces, pot holes and rough roads can be hazardous. Extreme caution is needed to avoid tipping the chair over.

It is important to climb or descend an obstacle slowly, cautiously and perpendicularly. Failing to do so may result in damage to the chair or causing bodily harm.



Do not exceed the incline guidelines and specifications in this owner's manual.





To navigate over a stationary obstacle:

- Approach the obstacle slowly, cautiously and perpendicularly.
- With extreme caution, increase the forward speed gently when the front wheels just come in contact with the obstacle and reduce the forward speed gently after the rear wheels cleared the obstacle.
- Lean your upper body slowly and slightly forward, when going over an obstacle with an ascending slope.
- With extreme caution, reduce the forward speed gently when the front wheels just come in contact with the obstacle and increase the forward speed gently after the rear wheels cleared the obstacle.
- Lean your upper body gently against the backrest, when going over an obstacle with a descending slope.
- Avoid any sudden stops and starts.
- Always navigate perpendicularly towards the obstacle.

Inclined Slopes

If you feel uncomfortable driving on a slope, do seek assistance to protect you from causing bodily harm to yourself.

- It is not advisable to drive on slopes over 10°.
- It is prohibited to drive on slopes over 12°.
- It is prohibited to drive on a wet slippery slope (e.g., snow, ice, oil etc.).
- It is prohibited to drive in areas with continuous up and down slopes

Reverse Driving

When driving in reverse, please exercise extreme caution. The motor wheels may run into an obstructive object which may lead to your chair getting out of control and may cause your chair to tip over.

- All obstructive objects should be cleared and approach cautiously and slowly while driving in reverse
- Never drive in reverse on inclined slopes

Load Limit


- Max Load of the chair: 500 lbs. (227 kg)
- Do not exceed the safe load of the backrest
- Do not press down or lift up the backrest.
- Under no circumstances should the user do weight training while using the chair.
- Overloading the chair may cause damage to the chair's frame, fastened parts and folding device.
- Overloading caused damages will void the warranty of the chair.

Getting Up/Down Stairs and Escalators The wheelchair is not designed for long journeys or getting up and down stairs, and escalators. It is prohibited to move or use wheelchair on stairs and escalators. Serious bodily injury may result.

Operation Guide

The Joystick comprises of the following:

- **Control Handle** - Controls the direction and speed of the chair. Push the joystick in the desired direction.
- **Power Switch** - Turns power on and off.
- **Battery Level Indicator** - Indicates the battery level.
- **Horn** - Press to sound horn.
- **Speed Up Button** - Increase the speed of the chair.
- **Speed Indicator** - With 5 LED lights on, the chair at its maximum speed. One LED light on, the chair is at its lowest speed.
- **Slow Down Button** - Pressing this button will slow the chair.
- **Charging Port** – The charger is plugged in here for on chair charging





Joystick

When operating the chair for the first time, it is recommended to set the chair at a low speed gently pushing the control joystick forward. The practice run will help you familiarize yourself with controlling the speed and start and stop of the chair.

Do not do sharp turns at high speeds. The chair could lose its balance and tip over causing serious bodily injury and property damage.

The joystick control handle on the control panel provides 360 degrees of maneuvering ability comfortably and effortlessly. A spring is equipped inside the joystick control handle that will automatically return to its neutral position when released.

Push the joystick towards the target direction. The joystick can control the drive speed proportionally; the harder the push, the faster it goes. The max traveling speed is 6km/hr.

Release the control joystick slowly and gradually for the chair to slow down safely. Sudden release of the control joystick may cause the chair to lose balance and tip over causing bodily injury.


Overview:


The controller controls advancing, reversing and turning of the wheelchair by independently controlling the forward and reverse rotation and speed of 2 brushless motors.

Major functions of controller:

- Control of motor direction and speed;
- Control of alarm buzzer;
- Control of motor solenoid valve;
- Indication of battery level and charging;
- Failure detection and alarming.

The controller has a built-in micro-controller which controls working logics by programming. Besides, the closed-loop control technology is used to control motor speed, such that the wheelchair is always under control on different roads.

Description of Motor Controller Port			
Connector Illustration	Description	Pins	Functions
	Power connector, connected to battery	1	Positive pole of power
		2	Negative pole of power
		3	Reserved pin
	Communication connector, connected to operation controller	1	Communication receiving
		2	Communication sending
		3	Power supply
		4	Earth wire
	Motor connector, the same for the left and right motors, connected to the brushless motors	1	Solenoid valve ground
		2	Solenoid valve power
		3	Hall power
		4	Hall phase A
		5	Hall phase B
		6	Hall phase B
		7	Hall ground
		8	Motor phase A
		9	Motor phase B
		10	Motor phase C

Description of Operation Controller Port			
Connector Illustration	Description	Pins	Functions
	Charging port, connected to charger	1	Positive pole of power
		2	Negative pole of power
		3	Charging indication control pin, charger terminal earthed



Basic Functions of the Controller

1) On/Off

Press the power switch at the OFF state, the controller will be turned on for self-check, and both the battery level indicators and speed indicators will light up for 2 seconds and then go out. At the non-charging mode, if the self-check is passed, the buzzer makes a short beep and then the controller goes into the normal operation mode. If the self-check fails, the buzzer makes a long beep for 5 seconds and then the controller goes into the error mode. For the specific error types, please refer to Troubleshooting of Controller; at the charging mode, the battery level indicators light up one by one, indicating that the controller is being charged.

At the ON state, press the power switch, and then all the indicators will go out and the system will be turned off.

2) Basic Operation for Driving

Pushing forward the control handle releases the brake and drives the motor to make the wheelchair move forward. The farther the handle is pushed, the faster the wheelchair moves. Similarly, by pushing back the control handle, the wheelchair moves backward; and by pushing it to left or right, the wheelchair turns. When the control handle is released it returns to neutral where the wheels are locked, and the chair won't roll.

In the following 3 cases, the control handle is unable to control wheelchair movement.

- 1 The wheelchair is being charged;
- 2 The battery level is low;
- 3 There's a failure

3) Speed Adjustment

The maximum speed of the wheelchair can be controlled through the speed-up button and slow-down button. The speed indicators indicate the maximum current speed. By pressing the speed-up button, the speed goes up by a level with 5 being the fastest level. By pressing the slow-down button, the maximum speed goes down by levels with 1 being the slowest level. During speed adjustment, the buzzer makes a short beep for indication. When the speed is at the extreme levels, i.e., the 1st or 5th level, the indicating sound is different from that at other levels.

4) Battery Level Indication

The battery level indicators indicate battery charge level. The more indicators are on, the higher the battery charge level. When the battery is almost out of power, only one indicator is on. If the battery level continues dropping, the indicator will flash, and the buzzer will make intermittent alarms to indicate that the battery needs to be charged.

When the battery level is lower than the minimum level for normal operation, the final indicator flashes quickly, the buzzer makes an alarm, meaning that the wheelchairs is disabled.

5) Battery Charging

The battery can be charged with the supplied charger. To charge the battery, connect the charger to the charging port and a standard power outlet.

For the charging state, please see the indicators on the charger. During charging, the controller can be turned on or off, and when it is on, it indicates the charging state. While charging, the control handle is ineffective, and the wheelchair cannot move.

6) Buzzer Alarm

Pressing the horn button and the buzzer beeps. Release the horn button and the buzzer stops beeping immediately. Pressing and holding the horn button will cause the horn to beep for a maximum of 10 seconds.

Trouble Shooting the Controller

The controller is provided with the failure detection function and detects failure at any state. When it detects a failure, it goes into the failure mode after the buzzer makes a long beep for 5 seconds.

In the failure mode, all the battery level LEDs flash, and the speed LEDs indicate the failure type. In the failure mode, there's no response to the operations of the control handle and buttons, and only the on/off switch is effective.

The chart on the next pages will provide the trouble codes, possible problems and possible solutions.



Speed Indicators	Failure Type	Failure Cause	Possible Solution
10010 	Left brake solenoid valve	Brake solenoid valve not closed	Close the brake solenoid valve
		Error in left motor solenoid valve	Check the motor connector
		Left motor solenoid valve or controller failure	Contact dealer for repair
10001 	Right brake solenoid valve	Brake solenoid valve not closed	Close the brake solenoid valve
		Error in right motor solenoid valve	Check the motor connector
		Right motor solenoid valve or controller failure	Contact dealer for repair
10100 	Hall failure of left motor	Motor wiring error	Check the motor connector
		Hall or controller motor failure	Contact dealer for repair
10011 	Hall failure right motor	Motor wiring error	Check the motor connector
		Hall or controller motor failure	Contact dealer for repair
00011 	Over-current of left motor	Over-current as a result of excessive wheelchair resistance	The system will recover after handle release
		Motor or controller failure	Contact dealer for repair
00001 	Over-current of right motor	Over-current as a result of excessive wheelchair resistance	The system will recover after handle release
		Motor or controller failure	Contact dealer for repair
00101 	Failure of handle zero point	Handle not at zero during power-on self-check	Turn power of and back on
		Handle or controller failure	Contact dealer for repair
00110 	Handle Failure	Handle or controller failure	Contact dealer for repair
00010 	Communication Failure	Controller wiring error	Check for loose connections or wiring errors



Braking

After any adjustment, repair or maintenance, check all components and parts for tightness before use, otherwise damage or injury may occur.

Electromagnetic Brake System

The chair has 2 braking modes which can be selected by pushing the brake levers to “Lock” or “Unlock” position.

- In “Lock” position: the internal clutch of the electromagnetic brake is engaged and the electromagnetic brake is started. Before powering on and attempting to operate the control joystick, the motor wheels will not move. Having brake in the “Lock” position will ensure the chair does not move, allowing the user to get on/off the chair safely and securely.
- In “Unlock” position: the internal clutch of the electromagnetic brake is disengaged. In “Unlock” position, the motor wheels can move freely even when the chair is powered off. This will allow the chair to move manually.

CAUTION - Before using the chair, it is important that the brake lever is in “LOCK” position and the electromagnetic brake is engaged to stop the rotation of the motor wheels. This will prevent any accidents from occurring and causing bodily injury.

1. Do not operate the chair while the brake is in “Unlock” position, without the presence of an attendant.
2. Do not seat yourself in the chair while the brake is in “Unlock” position, without any assistance from an attendant.
3. Do not place the chair on an incline or decline while the brake is in “Unlock” position, the chair may roll out of control and may cause damage to the chair or bodily harm.



Battery



Do not use batteries with different amp-hour (Ah) capacities.
Do not mix use of old and new batteries. Always replace both batteries at the same time.



Keep tools and other metal objects away from battery terminals. If contacted, short circuit or electric shock may occur and cause injury.



Avoid flammable materials. Avoid exposure to heat source such as open flame or sparks. Do not transport the batteries along with flammable or combustible objects.



Corrosive substance contained in the battery. Do not disassemble the battery.



Danger of explosion. When charging the batteries, place the chair and the battery charger in a well-ventilated area, away from flames and sparks.



WARNING

Do not attempt to connect the battery terminal directly using pliers or metal cables to charge the battery.

- Do not use the chair when the battery is being charged. An electronic drive locking device will be activated that prevents the chair from operating when battery being charged.
- Do not use non-standard power supply (eg. generator or inverter).
- Do not squeeze, bend, jerk or tie the power cord.
- Do not smoke or ignite anything around the battery.
- When pulling the power cord, grab the plug to pull it out.
- Keep the power cord away from children or pets.
- If there is any issue with the circuit breaker, pull out the charger immediately and contact your provider.
- The operating temperature of the battery is -5°C (23°F) to 40°C (104°F).

Battery Maintenance

The battery's life and performance may be affected by temperature, condition of the battery, and the weight of the user. Charging the battery continuously for a long duration before the first use can reduce the battery's service life. It is recommended that you charge the battery for the first time, when the lowest level of the LED light on the control panel flashes.

When charging a new battery for the first time, it must be fully charged (about 24 hours) in order to fully activate the battery.

Always ensure the battery is fully charged before use. The regular charging time is about 5 hours. But if the power is fully run out it may take 10-12 hours to charge fully until the red LED on the charger turns green. Thus, the recommended charging time for the battery is 8-12 hrs.


When not using the chair for a long duration, charge the battery full every 2 months. If the battery is left uncharged for a long period of time, it will damage the battery permanently.

Mounting/Removing Battery

Ensure the chair is powered off before mounting or removing the battery.

Taking out the battery:


1. The batteries are located under the wheelchair seat.
2. Press the lever below the battery and pull the battery out of the battery box (Fig. F)



F

Mounting the battery:

1. Hold the battery and plug in the battery to the battery holder box located below the wheelchair seat (Fig. G1).



Charging the Battery

The battery can be charged with normal AC power (AC 110-220 V, 50-60 Hz). The charging port is located under the front part of the control panel. Before charging ensure the chair is powered off.

1. Plug the charger cable into the charging port under the front part of the control panel
2. Plug the other side of charger into a power outlet. When the red LED is on, it is charging.
3. When the LED on the charger changes from red to green, keep charging for an additional 30 minutes to allow the battery to be fully charged.
4. Pull out the off-board charger from the power outlet before unplugging from the charging port of the control panel.
5. Please charge the battery in an appropriate temperature. The recommended ambient temperature for charging is between 5°C to -40°C.

Over-discharge Protector

The lithium battery will be permanently damaged, if the battery's capacity has been completely discharged. Therefore, wheelchair is equipped with an over-discharge protector. When the lithium battery is running out, the protector will cut off the circuit automatically and the controller will stop working.

When the lowest level red LED light on the battery level indicator flashes, it means that the batteries need to be charged.

When there is no red LED light on battery level indicator, it means that the batteries must be charged within 2 hours immediately. If not, the battery may not be activated permanently.

The charging time after over-discharge takes 10-12 hours.

When the lowest level LED light on the battery level indicator flashes, it means that the batteries need to be charged.

Battery Socket Cleaning

- Check the battery pack and the positive and negative poles for any corrosion. If any, clean with battery cleaning tools, steel brush or medium sand paper.
- When cleaning, Keep tools and other metal objects away from battery terminals. If contacted, short-circuit or electric shock may occur and cause bodily injury.



CAUTION - Do not allow the acidic substance inside the battery comes into contact with your skin, clothes or other items. The substance is extremely hazardous and may cause serious burn. When contacted, immediately flush your skin with cold water and seek medical attention.

Unfolding and Folding

After any adjustment, repair or maintenance, ensure all components are securely tightened.

 **When lifting the chair, it is strongly recommended to get the user off the chair before lifting or handling the chair. If absolutely necessary to handle the chair and yourself together, please exercise extreme caution and have at least two attendants to assist in lifting the chair. The front and rear edges of the seat base and frame should be held.**

Unfolding

1. As shown in Fig. H1, pull out the chair by holding the position shown in the figure as directed by the arrows.




H1

2. Pull the backrest till it straight as shown in Fig. H2



H2

3. Fix the folding release lever shown in Fig. H3.



H3

4. Mounting the joystick

4.1 The control panel is mounted on the armrest. As shown in Fig. I1-I3, vertically hold the joystick, align the screw hole of the control panel with the hole on the armrest and screw it tightly and securely.



I1



I2



I3

4.2 As shown in Fig. I4, connect the control panel cable of chair.



I4



4.3 As shown in Fig. I5 and I6, insert the plug of the control panel into the socket.



I5



I6

5. Fully expanded power wheelchair as below



Folding

1. Release the folding release lever under the chair seat as in Fig.K1 and K2



K1



K2

2. Fold the footrest as shown in Fig.L1



L1

3. Press the chair tightly following the arrow direction shown below



M1

4. Press the chair tightly till it fully closed.



Warranty

Wheelchair Frame: 5 Years

Motors 2 Years

Electrical Components 1 Year

Batteries: 1 Year

Other Components: 1 Year

Invoice is required for service within the warranty period, otherwise all repair costs will be charged. We will repair or replace at our option to the original purchaser, free of charge, any of the warranty included items being examined by an authorized representative of our company and found defective in material and/or workmanship. For repair beyond the warranty period, material costs will be charged, whereas the purchaser shall undertake the costs of transport.

Warranty Exclusions

1. The warranty exclusions extend to the following items:
 - a. Upholstery and seating, armrest, leg guard, footrest, brake pads, motor brushes, tires require replacement due to normal wear and tear.
 - b. Damaged components due to negligence, accident, misuse, abuse, overload commercial use, improper operation, maintenance or storage.
 - c. Circumstances beyond the control of our company.
 - d. Modifications and / or repairs made to the chair without consent in writing from our company.

2. If the serial number on the chair is not original or is modified, or is inconsistent with that on the warranty card, or the serial number on the warranty card is altered, warranty will be voided.
3. The warranty is non-transferable and is for the original purchaser of the chair only.

As a manufacturer, our responsibility is to repair or replace damaged parts. To the extent permitted by law, this warranty instruction supersedes any other warranties; such as writing, oral, expressive or implicit warranties, including warranties of any merchant ability or applicability of special purpose, for any conflicts between the same, this warranty instruction shall prevail.

Disclaimer

Thank you for purchasing our wheelchair. We disclaim all responsibility for any personal injury or property damage as a result of improper or unsafe use of this chair. If you have any questions about wheelchair and its safe operation, please feel free to contact your authorized provider.

Packing List

Main Wheelchair Frame	1
Joystick	1
User Manual	1
Charger	1
Storage Basket	1
Lithium Battery	1 (Additional batteries ordered separately)

Imported / Distributed by:

HPU Medical Wholesale
 34 Futurity Gate, Unit # 15
 Concord Ontario L4K 1S6
 Local: 416-739-8393
 Toll Free: 855-235-2400